



When the micro switch is engaged at idle it sends power from orange wire to black wire to engage the switch pitch function.


When the plunger is engaged at WOT it sends power from orange wire to white wire to engage the kick down function.



Idle micro switch jumps power across these two terminals



Wires to transmission



Idle micro switch

Linkage to carburetor

Linkage to gas pedal